

# SERAGE SERIES

# PLAYBACK & BACKUP

## INSTRUCTION GUIDE



DEFAULT  
USERNAME  
**admin**

DEFAULT  
PASSWORD  
**1**



Available on the  
**App Store**



**K** Viewer App

### HOW TO BACKUP:

**1** Press "Menu" button.

**3** Go to "Quick Search" or "Event Search" or "Calendar" & Press "ENTER"

**5** Press "Play" button.

**2** Go to "Search icon" and Press "ENTER"

**4** Specify the date and time desired, then Press "OK".

**6** To Finish PLAYBACK, Press "STOP" Button.

### HOW TO USB/DVD BACKUP:

**1** Format your Memory Stick and Plug it in the front USB port.  
  
(note: You can also use DVD+R type Disk).

**2** Press the "Backup" option available on the DVR's front panel. Or, press "Menu" then go to "Backup" option using Remote control or mouse.

**3** On the Backup setup page, make sure you choose the "Backup Device".

**4** Specify the START, END Date and Time desired to BACKUP. Press "OK" to start BACKUP. (Note: Make sure that both time & date are within the recorded data START TIME & END TIME).

**5** Take into consideration the Data Capacity to Backup/Use the "Estimate" option to double check the capacity required.

**6** An incremental backup percentage bar will be shown. Wait until the machine displays BACKUP SUCCESS.

**7** Viewer Software will be downloaded automatically.